

# itC Volume Controller

[ Please read the explanation before use or fix it!]


## Technology Information:

Model	T-671	T-672	T-673	T-674	T-675
Input Capacity	6W	15W	30W	60W	100W
Way	Transformer				
Level	11				
Installation	Surface mounted or Concealed installation				
Accessories	M4X25 Screw.....2				


## Installation Steps:

- 1 Position in the appropriate box at the end of the installation, and music signal box at the end of the lead line.
- 2 Retrieve volume controller, and the volume controller board connected to the connection, and that connection strong.
- 3 Qudiao volume control panel frame, this will be a good volume on the controller tightening screws.
- 4 Cancelled with the panel frame, audio-installed.

## Dimensions:



## Connection Method:



## Attention:

Suitable cable is IV or HIV type cable. Singlet line diameter is 0.8~1.4mm, cross sectional area is 0.5~1.5mm<sup>2</sup>. When playing music, signal will input from IN+, IN-.

# itC Volume Controller

[ Please read the explanation before use or fix it!]


## Technology Information:

Model	T-671	T-672	T-673	T-674	T-675
Input Capacity	6W	15W	30W	60W	100W
Way	Transformer				
Level	11				
Installation	Surface mounted or Concealed installation				
Accessories	M4X25 Screw.....2				


## Installation Steps:

- 1 Position in the appropriate box at the end of the installation, and music signal box at the end of the lead line.
- 2 Retrieve volume controller, and the volume controller board connected to the connection, and that connection strong.
- 3 Qudiao volume control panel frame, this will be a good volume on the controller tightening screws.
- 4 Cancelled with the panel frame, audio-installed.

## Dimensions:



## Connection Method:



## Attention:

Suitable cable is IV or HIV type cable. Singlet line diameter is 0.8~1.4mm, cross sectional area is 0.5~1.5mm<sup>2</sup>. When playing music, signal will input from IN+, IN-.

# itC Volume Controller

[ Please read the explanation before use or fix it!]


## Technology Information:

Model	T-671	T-672	T-673	T-674	T-675
Input Capacity	6W	15W	30W	60W	100W
Way	Transformer				
Level	11				
Installation	Surface mounted or Concealed installation				
Accessories	M4X25 Screw.....2				


## Installation Steps:

- 1 Position in the appropriate box at the end of the installation, and music signal box at the end of the lead line.
- 2 Retrieve volume controller, and the volume controller board connected to the connection, and that connection strong.
- 3 Qudiao volume control panel frame, this will be a good volume on the controller tightening screws.
- 4 Cancelled with the panel frame, audio-installed.

## Dimensions:



## Connection Method:



## Attention:

Suitable cable is IV or HIV type cable. Singlet line diameter is 0.8~1.4mm, cross sectional area is 0.5~1.5mm<sup>2</sup>. When playing music, signal will input from IN+, IN-.

# itC Volume Controller

[ Please read the explanation before use or fix it!]


## Technology Information:

Model	T-671	T-672	T-673	T-674	T-675
Input Capacity	6W	15W	30W	60W	100W
Way	Transformer				
Level	11				
Installation	Surface mounted or Concealed installation				
Accessories	M4X25 Screw.....2				


## Installation Steps:

- 1 Position in the appropriate box at the end of the installation, and music signal box at the end of the lead line.
- 2 Retrieve volume controller, and the volume controller board connected to the connection, and that connection strong.
- 3 Qudiao volume control panel frame, this will be a good volume on the controller tightening screws.
- 4 Cancelled with the panel frame, audio-installed.

## Dimensions:



## Connection Method:



## Attention:

Suitable cable is IV or HIV type cable. Singlet line diameter is 0.8~1.4mm, cross sectional area is 0.5~1.5mm<sup>2</sup>. When playing music, signal will input from IN+, IN-.